
CONTROLOF DRAINAGE PUMPS



The pump will start when the water level is above the sensor and stop when the water level is below the sensor. Protection to prevent ignition andvery continuous stops. Forced gear for 3s each week for pump protection.



- Electronic panel for the control of drainage pumps in car parks, garages, works, boats, etc.
- The level sensor is small and therefore ready for small spaces.
- Forced pump running to prevent poor pump condition during long idle periods.
- Equipment supply: 230VAC, 12-24VDC.
- Used for specific uses in emergencies and floods.
- Equipped with manual-stop-automatic selector.






Parking



Gardens



Boats



Garages

